

VINYL PLASTIC REPAIR KIT INSTRUCTIONS

1. Cut to required size depending upon hole or puncture.
2. Thoroughly clean damaged surface and allow to dry for a minimum of 10 minutes.
3. Remove vinyl patch from paper backing.
4. Press patch firmly over hole or puncture.
5. Do not inflate for 20 minutes.

MADE IN CHINA