

SPEKTRUM™

VRCONTROL

Bluetooth®

USE WITH
VIRTUALLY ALL
VR HEADSETS



Android/iOS
READY


FOR BLUETOOTH
ENABLED
SMARTPHONES

VIRTUAL REALITY BLUETOOTH® CONTROLLER

SPK-VRBTC1

VR Bluetooth® Controller

Note: Not all apps are compatible with Bluetooth® remote.



1. Remove cover from bottom of controller and insert two AAA batteries (not included).
2. Hold down the power button for 3 seconds to turn on controller. Repeat to turn off.
3. For the first time, it should start blinking. This means it is ready to pair with a device. Scan for Bluetooth® devices and choose the VR BOX Remote. The LED will stop blinking once paired.

Note: To connect the remote to a new device, the old device should be out of range or the Bluetooth® should be turned off on the device. Restart the remote and the remote will go into pairing mode after 5 second.

Android Instructions

1. The switch on the side of the remote should be switched to Android.
2. The device mode can be changed based on the function of the remote. **To change mode, press and hold @ then press any key (A/B/C/D).**

@ + A Music & Video Mode (One Handed)

Up/Down = Volume Up/Down
Left/Right = Next Track/Previous Track
C/D = Volume Up/Down
A = Play/Pause
R1 = Back

@ + B Horizontal Game Mode (Two Handed)

Controls app dependent

@ + C Vertical Game Mode (One Handed)

Controls app dependent

@ + D Mouse Mode (One Handed)

360° Rocker = Mouse Movement
C/D = Volume Up/Down
L1 = Select (Screen Press)

Apple® IOS Instructions

1. The switch on the side of the remote should be switched to IOS.
2. The device mode can be changed based on the function of the remote. **To change mode, press and hold @ then press any key (A/B).**

@ + A Music & Video Mode (Vertical/One Handed)

Right = Next Track (Flick)
Left = Previous Track (Flick)
Up = Volume Up
Down = Volume Down
A = Mute
B = Play/Pause
C/D = Volume Up/Down
R1 = Home Button
L1 = Nothing

@ + B Game Mode (Horizontal/Two Handed)

Controls app dependent

3. This controller works with apps designed with iCade style controls. In the Apple App Store, search "iCade" to find compatible apps.

Troubleshooting

- If controller is not responding, remove batteries and reinsert batteries. Then power on. If it is still not responding, replace batteries.
- If controller fails to change modes, restart controller and try again.
- Low batteries can cause the 360° Rocker to lose sensitivity or malfunction. Replace batteries if this occurs.
- If the controller cannot be found while pairing, turn Bluetooth® off and back on. Restarting your device and the controller may help.
the controller may help.

Technical Parameters

Product model: VR Remote Controller
Size: 118*33*42MM
Wireless Protocol: Bluetooth 3.0 compliant
Support System: Android/IOS/PC
Support Game: Android/PC (GAMEPAD)
NES/GB/SMDSX/GBC/N64/MAME; AndrodAPK
Game Apple/IOS: Icade Game
Battery: AAA x2
Not included in the package
Working Current: 0.5-8Ma Standby Current: 0.5-1mA
Continuous Game Time: about 40-120 hours